

# 計算結果 単位はKm/hです

ノーマル 53/11

	1速	2速	3速	4速	5速	6速
0rpm	0	0	0	0		
1000rpm	2	3	4	5		
2000rpm	3	5	8	10		
3000rpm	5	8	12	15		
4000rpm	6	11	16	20		
5000rpm	8	14	20	25		
6000rpm	10	16	24	30		
7000rpm	11	19	28	36		
8000rpm	13	22	31	41		
8500rpm	14	23	33	43		
9000rpm	15	25	35	46		
9500rpm	15	26	37	48		
10000rpm	16	27	39	51		
10500rpm	17	29	41	53		
11000rpm	18	30	43	56		
11500rpm	19	31	45	58		
12000rpm	19	33	47	61		
12500rpm	20	34	49	64		
13000rpm	21	36	51	66		

# 計算結果 単位はKm/hです

改造後 53/15

	1速	2速	3速	4速	5速	6速
0rpm	0	0	0	0		
1000rpm	2	4	5	7		
2000rpm	4	7	11	14		
3000rpm	7	11	16	21		
4000rpm	9	15	21	28		
5000rpm	11	19	27	35		
6000rpm	13	22	32	42		
7000rpm	15	26	38	49		
8000rpm	18	30	43	55		
8500rpm	19	32	46	59		
9000rpm	20	34	48	62		
9500rpm	21	35	51	66		
10000rpm	22	37	54	69		
10500rpm	23	39	56	73		
11000rpm	24	41	59	76		
11500rpm	25	43	62	80		
12000rpm	27	45	64	83		
12500rpm	28	47	67	87		
13000rpm	29	49	70	90		

# 計算結果 単位はKm/hです

適正化 53/14

	1速	2速	3速	4速	5速	6速
0rpm	0	0	0	0		
1000rpm	2	3	5	6		
2000rpm	4	7	10	13		
3000rpm	6	10	15	19		
4000rpm	8	14	20	26		
5000rpm	10	17	25	32		
6000rpm	12	21	30	39		
7000rpm	14	24	35	45		
8000rpm	17	28	40	52		
8500rpm	18	30	43	55		
9000rpm	19	31	45	58		
9500rpm	20	33	48	61		
10000rpm	21	35	50	65		
10500rpm	22	37	53	68		
11000rpm	23	38	55	71		
11500rpm	24	40	58	74		
12000rpm	25	42	60	78		
12500rpm	26	44	63	81		
13000rpm	27	45	65	84		